




SmartExhaust™ Testing Guide



With power to the SmartExhaust™ switch -

ACTION				
	1	2	3	4
	Turn Delay and Ventilation dial to 30 minutes, flip switch to ON 	Wait 15 seconds, flip switch to AUTO 	Turn Delay dial to 0 minutes, wait 15 seconds 	Turn Ventilation dial to 60 minutes, wait 15 seconds 
RESPONSE	Light and fan should come on	Light should go off and fan should continue to run	Fan should go off	Fan should go on

TESTING COMPLETE. RETURN DIALS TO PREFERRED SETTINGS.

If after following this procedure the SmartExhaust™ is not responding properly please contact Technical Support at info@aircycler.com.